

# Precision Strobe Tuner

## Operation Manual PST-4




### Table of Contents:

- 1.0 PST-4 Operations Summary
- 2.0 General Operation
  - 2.1 Getting Started
  - 2.2 Calibration Adjustment
  - 2.3 Filter Modes
  - 2.4 Auto Track Mode
  - 2.5 Programmable Memory Operation
  - 2.6 Save Settings Mode and Power Down Timer
  - 2.7 Battery Charger Operation
- 3.0 Applications
  - 3.1 Guitar Tuning
  - 3.2 Guitar Intonation Adjustment
  - 3.3 Piano Tuning Tips
  - 3.4 Piano Tuning Background
  - 3.5 Piano Tuning Operations
  - 3.6 Piano Stretch Curve Construction
  - 3.7 PST-4 Stretch Curve Function

### Appendices:

- A, The Equal Tempered Scale
- B, Piano Stretch Curve Data
- C, Alternative Temperaments
- D, Cents to A Frequency Conversion Table
- E, Other Instrument Tunings
- F, Further Reading
- G, PST-4 Specifications

# 1.0 PST-4 Operation Summary



## Strobe Display

The outside ring of LEDs forms the Strobe Display. When the Input Pitch is within about a semi-tone of the internal Reference Pitch (Note Setting), a two group pinwheel of LEDs opposite each other will appear to rotate in the Strobe Display. The rotation direction indicates whether the input tone is sharp or flat and rotation speed indicates degree of error. The speed of rotation decreases as the Input Pitch is brought in tune and appears stationary when the Note Setting is exactly matched.

## Sharp/Flat Indicator Display

Indicates coarse tuning error, much like a needle type tuner. Use this for coarse tuning direction when the Strobe Display pattern rotation is too fast to be perceptible.

## Note/Octave Display Rings

Read the Note and Octave Setting from Note and Octave Indicators inside the Strobe Display.

## Numeric Display

Press the Cal button to display and adjust calibration:

[ 00.0]: Calibration Setting Display in Cents

Press the Mode button to display and adjust the Note/Octave Setting:

[A 5]: Note Setting, A, 5th Octave

## Adjust Knob

In Note Display Mode, rotate to change Note Setting. In Calibrate Mode rotate to change the tuner calibration as indicated in cents. In other modes rotate to index the displayed parameter.

## Cal Button

Press to change to Calibration Display Mode. The Numeric Display will change to [ 00.0], with one of the digits flashing. Calibration is displayed in cents deviation from an equal tempered based on a 440Hz A with flat designated "-". Rotate the Adjust Knob to change the value of the flashing digit. Click the Cal Button to change which digit is flashing. When a Memory Bank is enabled, holding the Cal Button down displays and allows adjustment of the Calibration Offset.

## Mode Button

When in Note Display Mode, press the Mode Button momentarily to select the Operation/Filter Mode display. Press the Mode Button again to return to Note Display Mode. When in Calibration Display Mode, press the Mode Button to return to Note Display Mode. When in Note Display Mode, click the Mode Button quickly to change to Octave Index Mode. The Octave digit will begin flashing. Rotating the Adjust Knob will now index the Note Octave. Click the Mode button again to return back to Normal Index Mode.

## Operation/Filter Modes

To change the Operation/Filter Mode, press the Mode Button momentarily while in Note Display Mode. The display will change to show the current Operation/Filter Mode. Rotate the Adjust Knob to cycle through the filter modes:

[ bb ]	Band Pass, Base Boost Enable, Chromatic
[ AP ]	All Pass, Chromatic
[ LP ]	Low Pass, Chromatic
[ bP ]	Band Pass, Chromatic
[ gu ]	Auto, Guitar Mode
[bass]	Auto, Bass Guitar Mode

Press the Mode Button again to return to Note Display Mode.

## Auto Button

Press the Auto Button to enable Auto Track Mode. The Auto Indicator will light, and the PST-4 will automatically track the input note. Press again to disable.

## Programmable Memory Operations

The Programmable Memory allows the user to preset a Temperament into the PST-4 by programming a separate Calibration Adjustment setting for each of the 88 notes. The Temperament is defined in terms of cents deviation from the Equal Tempered scale. This can be setup however a user desires, for example, a Just Toned scale can be configured, or the stretch of a piano can be programmed. 40 pages of memory are provided, each containing 88 notes.

## Select Memory Bank

Hold the Mem Button down, the display will show: [b 1]. Rotate the Adjust Knob while holding the Mem button down to index through, and select one of the 40 Memory Banks. Release the Mem button. The Mem indicator LED will be lit to signify a Bank is active. As the Note setting is changed, the corresponding calibration value from the selected Bank will be updated to the Cal display. These banks must be programmed by the user.


## Pitch Offset

Pitch Offset is used to shift the entire Memory Bank Sharp or Flat. The Offset is displayed while the Cal Button is held down. To adjust the offset, turn the Adjust Knob while holding down the Cal Button. The flashing digit will be indexed. When the button is released, the memory setting for the current note will be restored to the display. Click the Cal button to change which digit is flashing.

## Programming a Memory Bank

Select the desired Bank to be programmed as described above. Unlock the selected Bank by pressing the Cal Button while holding down the Mem Button. The Mem and Unlock indicators should both light. Each of the notes in the selected Bank can now be changed. Press the Mode button if needed to return to Note Display Mode and select the first note to be programmed, next press the Cal button and adjust the calibration for the selected note. Repeat, setting each note to the desired value. When done, click the Cal button while holding the Mem button down to relock the memory.





With the PST-4 set in All Pass filter mode, instruments producing tones with high harmonic content will produce a Strobe Display with all these harmonics superimposed. The resulting display may be very garbled looking and difficult to interpret, particularly during the attack. For example, a guitar string plucked near the bridge will produce a complex display, which settles to the two group fundamental pattern as the overtones decay. A guitar string gently plucked in the center produces a two group display from the start. The Low Pass and Band Pass Filter Modes are used to obtain a clear two group pinwheel display right from the note start.

Using the Band Pass Mode it is possible to individually measure the harmonics of a tone. This is useful for measuring string inharmonicity. Inharmonicity is the degree to which the frequencies of overtones differ from whole multiples of the fundamental frequency. For example, to measure the octave harmonic (2nd partial) of the 4A string, set the PST-4 to 4A and tune the string until rotation is stopped. Next, set the tuner to 5A and play the 4A string. The string fundamental will be filtered out, leaving only the 2nd partial in the display. Notice that the octave harmonic is slightly sharp. Adjust the tuner Calibration until rotation is stopped. The calibration setting is the level of inharmonicity for the 2nd partial.

## 2.4 Auto Mode

In Auto Mode the PST-4 tracks the input Note, allowing hands free operation for most tuning operations. Press the Auto Button to enable Auto Mode and the Auto LED indicator in the center of the display will light. Press the Auto Button again to disable. In some situations with very high harmonic content, such as the very low end of the piano, Auto Mode may not track well and jump between octaves. In this case, disable Auto Mode and manually select the Note Setting.

## 2.5 Programmable Temperament Operation

The PST-4 provides 40 user programmable Memory Banks. This allows the user to program a separate calibration setting for each of the 88 notes. These calibration settings are recalled whenever the Note Setting is changed. This is useful for storing piano stretch curves, or for tuning to alternate temperaments.

To enable and select a Memory Bank, press down and hold the Mem Button. The display will change to [b 1], which signifies Bank 1. While holding the Mem Button, rotate the Adjust Knob to index to the desired Bank. Release the Mem Button, and the Mem Indicator in the center of the display will light, showing that a Memory Bank is enabled. Now press the Cal Button, and note that the calibration is not adjustable, as it is now set to whatever value is in the Memory Bank. When in Memory Bank Mode and Calibration Display Mode, the Adjust Knob indexes the selected Note, as shown by the Note/Octave Indicators inside the Strobe Display.

When operating in Memory Bank Mode, the entire Bank can be offset Sharp or Flat. To adjust the Calibration Offset, press and hold the Cal Button, then rotate the Adjust Knob. Clicking the Cal Button will change which digit is flashing and adjusted when rotating the Adjust Knob.

To program a Memory Bank, first select and enable one of the 40 Banks. The Mem Indicator should be lit. Next, press and hold the Mem Button, then click the Cal Button to unlock the Bank. Now the Unlock Indicator should be lit as well. Press the Mode Button if not in Note Display Mode, and select the first note to be programmed. Press the Cal Button to change to Calibration Display Mode and then adjust the calibration for the given note to the desired value. Press the Mode Button again to return to Note Display Mode and repeat until all the desired notes are programmed. Press and hold the Cal Button and click the Cal Button to relock the Memory Bank.

There is also a Bank Copy feature to allow you to copy a Memory Bank into another Bank. To use this function:

1. Hold down the Temp Button while turning the power on. Keep it down until the PST-4 is running. The Copy Bank Mode is now enabled.
2. Next, press the Mode button. The display changes to [CS 1], which signifies Copy Source Bank parameter setup.
3. Press the Mode Button to index through the parameters:

[CS n] – Copy Source Bank n  
 [CD n] – Copy Destination n  
 [CE -] – Copy Enable

4. Use the Mode Button to index to Copy Source display [CS x] and rotate the adjust knob to select the Source Bank.
5. Use the Mode Button to index to Copy Destination display [CD x] and rotate the adjust knob to select the Destination Bank.
6. Use the Mode Button to index to Copy Enable display [CE -] and rotate the adjust knob to select [CE C].
7. Initiate the copy operation by pressing and holding the Mode Button down until the display shows [coPy]. When the display shows [donE] the copy is complete.
8. Turn the Power off, and then on, to return to normal operation mode.

To zero out a previously programmed bank, follow the above procedure using bank zero as the Source Bank, and the Bank to be zeroed as the Destination Bank.

## 2.6 Output Jack Function Selection

The Output Jack can be configured to either output the internal reference frequency to an amplifier, or pass the Input Jack signal thru to the Output Jack. Internal jumpers JP8 (2 pins, between the Input and Output Jack), and JP9 (4 pins, below the Output Jack) on the circuit board must be moved to change the configuration. For signal Input thru to Output configuration, place one shorting jumper on JP9 and one jumper in the center position of JP8 (shorting pins 2-3). For Reference Tone output to the Output Jack, remove the jumper from JP9, and place both jumpers on JP8, shorting pins 1-2 and 3-4.

## 2.7 Save Settings Mode and Power Down Timer

The PST-4 can be configured to retain the last Note and Mode settings on power up. It can also be configured to automatically turn off after a period of inactivity to save batteries. To enable Save Settings Mode or the Power Down Timer Mode:

1. Hold down the Mode Button while turning the power on. Keep it down until the PST-4 is running, then release. The Settings Mode is now enabled.
2. Press and hold the Mode Button until the display changes to [SS d], which signifies Save Settings Mode is set to disabled.
3. Notice that at this point you can press the Mode Button to index through the parameters:

[SS x] – Setting Save

[Pd x] – Power Down

4. To change the Settings Save Mode, use the Mode Button to index so the display shows [SS d], rotate the Adjust Knob to change between Enabled (E) and disabled (d).
5. To change the Power Down Timer Mode, use the Mode Button to index to the display [Pd 0], rotate the Adjust Knob to change between 0 (off), 5, 10 and 30 minutes.
6. Turn the Power off, and then on, to return to normal operation.

## 2.8 Battery Charger Operation

The PST-4 will operate from either an external power supply or internal batteries. Six AA batteries are required. A built in battery charger for NiMH type batteries is provided. The PST-4 will operate for 10 to 15 hours from 1800mAH batteries.

The battery charger is a timed charger and will charge 1800mAH batteries in 15 hours. To initiate a charge cycle, first plug in the external power supply and turn the tuner on. Then, press and hold the On/Off button for about three seconds until the display shows [Chrg]. Release the On/Off button. The display will alternate between the [Chrg] message, and the remaining charge time. Rotate the Adjust Knob to select a charge time of 1, 3, 5, 10 or 15 hours.

A discharged set of 1800mAH capacity batteries will be fully charged in 15 hours. Service lifetime of NiMH batteries will be reduced if repeatedly overcharged, so only charge for the full 15 hours when the batteries have been fully discharged. The batteries should be charged about 1.5 hours for every hour of tuner operation to top off the battery charge.

To install or change the batteries, unscrew the 4 rubber feet and remove the back cover. Install the batteries and make sure the battery wire is plugged in correctly (Red wire toward the + marking on the PCB). If alkaline batteries are installed, you MUST move the shorting bar on JP7 (3 pin, above power jack) to the OFF position to disable the charger. Set it to the ON position for NiMH batteries.

**Warning:** Do not attempt to charge alkaline batteries. If you do, very bad things may happen which might not please you. Be advised.

## 3.0 Applications

### 3.1 Guitar Tuning

The Note Settings to use for E tuning of the guitar and base guitar strings are:

#### Guitar

[E 2] Low E String

[A 3] A String

[D 3] D String

[G 4] G String

[B 4] B String

[E 4] High E String

#### Bass

[E 1] Low E String

[A 2] A String

[D 2] D String

[G 2] G String

Plug an electric guitar directly into the Signal Input Jack. Hold an acoustic close to the Mic input. Pluck the string and tune to stop Strobe Display rotation. When using Auto Mode while tuning an acoustic with bright strings, the tuner may jump to string harmonics during the attack. If this is a problem, use Guitar Operation Mode [gu ], to improve note detection stability. Use Bass Operation Mode [bass], for optimal stability when tuning bass guitars.

### 3.2 Guitar Intonation Adjustment

Guitar Intonation setup involves adjusting the length of the strings at the tailpiece such that a note played on the twelfth fret of each string is a true octave of the open string. If the length is adjusted too short, the fretted octave will ring sharp compared to the open string. The tail-piece is adjusted to correct the fretted octave. Alternately, All Pass filter Mode can be used for this measurement to view the fretted octave as a harmonic of the open string frequency directly. Enable All Pass Filter Mode, turn Auto Mode off, set the Note Setting to the open string note and pluck lightly in the string center to view it's fundamental. Then, play at the twelfth fret, and read the four group octave display pattern in the Strobe Display.

### 3.3 Piano Tuning Tips

Piano strings in the low octave tend to ring with the fundamental at a much lower level than the harmonics. Use the Bass Boost Filter Mode [bb ], to improve the Strobe Display in this range. It is also recommended that an external microphone with good low frequency response be used when measuring the fundamental of strings in low octave of a piano.

### 3.4 Piano Tuning Background

A skilled technician can tune the middle C string of a piano to a single tuning fork and then tune all the remaining strings, doing this entirely by ear. The first step is tuning the temperament octave. It is done by listening to the beats produced between the partials of certain intervals and tuning that interval by tuning the beat to the proper rate. Once the temperament octave has been tuned, the remaining strings are tuned to it. This is done by progressively playing octave intervals up and down the keyboard, while tuning to remove the beat. The origin of the beat, and how they are used in this process is explained in detail in many books on the subject. See Appendix D.

Once a piano has been tuned by this method, if you measure all of the notes against an equal tempered scale and plot the data, you will find an interesting result. Toward the high end of the piano, the notes will progressively get sharper, with the highest note perhaps 30 cents sharp, there is also a similar flattening of the lowest notes, although not as pronounced.

This is due to the inharmonicity of ringing strings. A string can ring in several modes of vibration, the fundamental, and a series of harmonics over integer division subsections of the string. Note A3 produces the approximate harmonic series of 110 Hz, 220 Hz, 330 Hz etc. The frequencies are determined by string length, mass, tension and stiffness. The harmonics ring on shorter sections of string which have a higher thickness to length ratio, and are therefore stiffer. This extra stiffness causes the harmonics to ring slightly sharper than the ideal harmonics.

The actual frequencies which ring are known as partials. The fundamental is called the 1st partial, and the first octave harmonic the 2nd partial etc. How much sharper the partials are than ideal harmonics depends on the string geometry. When a tuner is tuning the octave intervals up the keyboard, they are generally listening to the beat produced between the fundamental of the higher string, and the 2nd partial of the lower string. This generates a slightly sharp octave when comparing the fundamentals, which accumulates up the keyboard, resulting in the tuning stretch curve for a piano. This stretch curve varies from piano to piano, depending on the string arrangement.

### 3.5 Piano Tuning Operations

Pianos have groups of up to three strings per note, which are known as unisons. When tuning the temperament only the center string of each unison is tuned. This can be done using rubber wedges to damp out the two outside strings while tuning the middle string. Then these can be removed one at a time while tuning the outside string to the center string, a process call tuning the unisons. A length of felt can also be folded and tucked into the space between unisons to damp the outside strings over an interval. This is handy when setting the temperament octave.

Final tuning of the unisons can be performed by ear by playing each outside string along with the center string, then tuning the outside string while listening to the beat and tuning to remove it. When playing two strings at once into the PST-4, the rotation of both notes are displayed, superimposed, giving a pulsing display, settling to a stable two group pinwheel when the beat is stopped. The remaining unison strings can also be tuned separately, tuning each to stop the rotation.

### 3.6 Manual Piano Stretch Curve Construction

The stretch curve for a given piano can be tuned using a series of string partial measurements. The temperament octave is first tuned directly to 0.0 cents. Then the strings are tuned up the keyboard by tuning each string fundamental to the 2nd partial of the string an octave lower. This curve can be stored in one of the PST-4 Temperament Banks, and used for directly tuning the string fundamentals again later. The following procedure is based on the one given by Reblitz (See Appendix D).

1. Using a felt strip, damp out the outside strings from E3 to E4.
2. If saving results in a Temperament Bank, select which one, and zero it.
3. Verify Calibration is set to 0.0 and tune the center strings of the temperament octave unisons from F3 to E4.
4. Beginning with note F3, measure the string 2nd partial, and tune the string one octave higher, F4, to this value.
  1. Set the Note Setting to [F 4].
  2. Play note F3 and measure its 2nd partial by adjusting the Calibration until rotation is stopped.
  3. Play note F4 and tune it's fundamental to stop rotation.
  4. Program this value into Bank Setting [F 4] if desired.
5. Repeat step (4) for each progressive note up the keyboard until you have tuned up to [C 8].
6. Beginning with [Eb 3], tune it such that it's 2nd partial is matched to the fundamental of the string one octave higher, [Eb 4].
  1. Set the Tuner to [Eb 4]. Play Eb4 and adjust the Tuner Calibration until rotation is stopped.
  2. Play the Eb3 note and tune it's first partial to stop rotation.
  3. Set the Tuner to [Eb 3].
  4. Play the Eb3 note, and adjust the Tuner Calibration to stop rotation. This is the Cal Setting to tune the [Eb 3] fundamental to. Program this value into the [Eb 3] Bank if desired.
7. Repeat step (6) progressively down the keyboard until you have tuned down to [A 1]. The stretch curve for the piano has been set into the Temperament Bank.
8. Tune all of the remaining strings of the unisons.

### 3.7 PST-4 Stretch Curve Construction

The stretch curve for a given piano can also be determined directly from a set of differential measurements, without actually tuning the piano first. This can be done by measuring the fundamental and the 2nd partial of each string, then taking the difference to find the 2nd partial inharmonicity of each string. These values can then be used to construct the stretch curve. This can be done by hand, using a spreadsheet, or by using the PST-4 special Bank Copy function.

The PST-4 has a special Bank Copy Mode which will construct a stretch curve from two sets of measurements. The first is a set of measurements of the fundamental of strings A1 up to C7. The second is a set of measurements of the 2nd partial of each of these strings. These two measurement sets are stored in special purpose Banks. Bank 41 is used for the fundamental measurements. Bank 42 is used for the 2nd partial measurements. The stretch curve is then automatically figured from these two Memory Banks by the PST-4 using the special Bank Copy function, which stores the result in Bank 43.

1. Measure the fundamental of strings A1 to C7 and store into Temperament Bank 41.
  1. Select Temperament Bank 41 and Unlock the Bank.
  2. Set the PST-4 to note A1. Play note A1 and adjust the Calibration Knob until Strobe Display rotation is stopped.
  3. Repeat step (1.2) up the keyboard to Note C7. The tuning of the fundamental note of all but the high Octave is now stored in Temperament Bank 41.
2. Measure the 2nd partial of strings A1 to C7 and store as notes A2 to C8 in Temperament Bank 42.
  1. Select Temperament Bank 42 and Unlock the Bank.
  2. Set the PST-4 to note A2. Play note A1 and adjust the Calibration Knob until Strobe Display rotation is stopped.
  3. Repeat step (2.2) up the keyboard to Note C7 ending with this partial being stored into Note C7. The tuning of the 2nd partial of the lower 7 octaves are now stored into Temperament Bank 42, starting at note A2 up to note C8.
3. You are now ready to use the PST-4 to generate the stretch curve and put into Temperament Bank 43.
4. Enable the Copy Bank Functions: Turn the PST-4 off. Hold down the Temp button down while turning the power on, keeping it held down until the PST-4 becomes active, then release.
5. Perform the differential copy to generate the stretch curve. The PST-4 must first be turned on with the Temp Button held down to enable the Bank Copy functions.
  1. Press and hold the Mode Button until the display changes to [CS 1].
  2. Press and release the Mode Button and index until the display shows [CE -].
  3. Rotate the Adjust Knob to index to [CE d], which signifies differential Copy Mode.
  4. Press and hold the Mode Button until the display changes to [dstr]. The process is complete when the Display flashes [donE].
6. The stretch curve is now stored in Temperament Bank 43. You can copy it down to some other Bank for permanent storage, and use it to tune the fundamental of each note to the stretch curve.


## Appendix A, The Equal Tempered Scale

N	Not e	Freq	N	Not e	Freq	N	Not e	Freq
0	A1	27.500	36	A4	220.00	72	A7	1760.00
1	Bb1	29.135	37	Bb4	233.08	73	Bb7	1864.66
2	Bb1	30.868	38	Bb4	246.94	74	Bb7	1975.53
3	C1	32.703	39	C4	261.63	75	C7	2093.00
4	Db1	34.648	40	Db4	277.18	76	Db7	2217.46
5	D1	36.708	41	D4	293.66	77	D7	2349.32
6	Eb1	38.891	42	Eb4	311.13	78	Eb7	2489.02
7	E1	41.203	43	E4	329.63	79	E7	2637.02
8	F1	43.654	44	F4	349.23	80	F7	2793.83
9	Gb1	46.249	45	Gb4	369.99	81	Gb7	2959.96
10	G1	48.999	46	G4	392.00	82	G7	3135.96
11	Ab1	51.913	47	Ab4	415.30	83	Ab7	3322.44
12	A2	55.000	48	A5	440.00	84	A8	3520.00
13	Bb2	58.270	49	Bb5	466.16	85	Bb8	3729.31
14	Bb2	61.735	50	Bb5	493.88	86	Bb8	3951.07
15	C2	65.406	51	C5	523.25	87	C8	4186.01
16	Db2	69.296	52	Db5	554.37			
17	D2	73.416	53	D5	587.33			
18	Eb2	77.782	54	Eb5	622.25			
19	E2	82.407	55	E5	659.26			
20	F2	87.307	56	F5	698.46			
21	Gb2	92.499	57	Gb5	739.99			
22	G2	97.999	58	G5	783.99			
23	Ab2	103.83	59	Ab5	830.61			
24	A3	110.00	60	A6	880.00			
25	Bb3	116.54	61	Bb6	932.33			
26	Bb3	123.47	62	Bb6	987.77			
27	C3	130.81	63	C6	1046.50			
28	Db3	138.59	64	Db6	1108.73			
29	D3	146.83	65	D6	1174.66			
30	Eb3	155.56	66	Eb6	1244.51			
31	E3	164.81	67	E6	1318.51			
32	F3	174.61	68	F6	1396.91			
33	Gb3	185.00	69	Gb6	1479.98			
34	G3	196.00	70	G6	1567.98			
35	Ab3	207.65	71	Ab6	1661.22			

$$F(N) = 27.5 * 2^{(N/12)}$$

$$N(F) = (12/\ln(2)) * \ln(F/27.5)$$

## Appendix B, Piano Stretch Curve Example, Yamaha Upright



Note	Cents	Note	Cents	Note	Cents
A1	-3.4	A4	-0.3	A7	6.2
Bb1	-3.3	Bb4	-0.2	Bb7	6.8
Bb1	-3.2	Bb4	-0.1	Bb7	7.5
C1	-3.2	C4	0.0	C7	8.3
Db1	-3.2	Db4	0.2	Db7	9.1
D1	-3.1	D4	0.3	D7	10.0
Eb1	-3.1	Eb4	0.4	Eb7	11.0
E1	-3.1	E4	0.5	E7	12.0
F1	-3.1	F4	0.5	F7	13.1
Gb1	-3.1	Gb4	0.6	Gb7	14.3
G1	-3.1	G4	0.7	G7	15.5
Ab1	-3.0	Ab4	0.8	Ab7	16.8
A2	-3.0	A5	0.8	A8	18.1
Bb2	-3.0	Bb5	0.9	Bb8	19.5
Bb2	-3.0	Bb5	1.0	Bb8	20.9
C2	-2.9	C5	1.0	C8	22.4
Db2	-2.8	Db5	1.1		
D2	-2.8	D5	1.2		
Eb2	-2.7	Eb5	1.2		
E2	-2.6	E5	1.3		
F2	-2.5	F5	1.4		
Gb2	-2.4	Gb5	1.5		
G2	-2.3	G5	1.6		
Ab2	-2.2	Ab5	1.7		
A3	-2.1	A6	1.9		
Bb3	-1.9	Bb6	2.1		
Bb3	-1.8	Bb6	2.2		
C3	-1.7	C6	2.5		
Db3	-1.5	Db6	2.7		
D3	-1.4	D6	3.0		
Eb3	-1.2	Eb6	3.3		
E3	-1.1	E6	3.7		
F3	-0.9	F6	4.1		
Gb3	-0.8	Gb6	4.5		
G3	-0.6	G6	5.0		
Ab3	-0.5	Ab6	5.6		

## Appendix C, Alternative Temperaments

Note	Equal	Just	Pythagorean	Mean
A	0.0	0.0	0.0	0.0
Bb	0.0	33.2	-9.8	17.6
B	0.0	3.9	3.9	-6.4
C	0.0	15.6	-5.9	10.4
Db	0.0	-13.7	7.8	-13.3
D	0.0	19.6	-2.0	3.6
Eb	0.0	31.3	-11.8	20.7
E	0.0	2.0	2.0	-3.3
F	0.0	13.7	-7.8	13.6
Gb	0.0	-15.6	5.9	-9.7
G	0.0	17.6	-3.9	7.0
Ab	0.0	-11.7	9.8	-17.0

## Appendix D, Cents to A Frequency Conversion Table

F(A)	Cents	f(A)	Cents	f(A)	Cents	F(A)	Cents
430.0	-39.8	435.0	-19.8	440.0	0.0	445.0	19.6
430.5	-37.8	435.5	-17.8	440.5	2.0	445.5	21.5
431.0	-35.8	436.0	-15.8	441.0	3.9	446.0	23.4
431.5	-33.8	436.5	-13.8	441.5	5.9	446.5	25.4
432.0	-31.8	437.0	-11.8	442.0	7.9	447.0	27.3
432.5	-29.8	437.5	-9.9	442.5	9.8	447.5	29.3
433.0	-27.8	438.0	-7.9	443.0	11.8	448.0	31.2
433.5	-25.8	438.5	-5.9	443.5	13.7	448.5	33.1
434.0	-23.8	439.0	-3.9	444.0	15.7	449.0	35.1
434.5	-21.8	439.5	-2.0	444.5	17.6	449.5	37.0
						450.0	38.9

## Appendix E, Other Instrument Tunings

Violin: G3, D4, A5, G5.

Banjo C Tuning: G4, C3, G3, B4, D4

## Appendix F, Further Reading

Piano Servicing Tuning & Rebuilding  
Arthur A. Reblitz (1993), The Vestal Press

PIANO TUNING, A Simple and Accurate Method for Amateurs  
J. Cree Fischer (1907)

The Science of Sound  
Thomas D. Rossing (1982), Addison-Wesley Publishing

The Acoustical Foundations of Music  
John Backus (1977), W W Norton and Company

The Equal Tempered Scale and Some Peculiarities of Piano Tuning  
<http://www.precisionstrobe.com/apps/pianotemp/temper.html>

"The Endangered Piano Technician"  
Essay, James Boyk, Scientific American December 1995

THE SEVENTH DRAGON: The Riddle of Equal Temperament  
Anita T. Sullivan (1985), Metamorphous Press.

## Appendix G, PST-4 Specifications

Dimensions: 3.5 x 5.6 x 1.4 inches  
(excluding knob)

Power Supply: 12 Volts DC, 300 mA  
(Center Pin Positive)

Accuracy:  
Temperament (Note Spacing); better than .01 Cent  
Absolute; .1 Cent.

Temperature  
Drift: Less than .1 Cent over  
0° C to 40° C.

Tuning Range: A1 to C8

Calibration Range:  $\pm 80$  Cents in  
.1 Cent Increments

Temperament Memories: 40 Banks, 88 Notes Each

Software Version: 1.0

(Manual Rev 4B)  
Jim Campbell  
Ann Arbor, MI  
[www.precisionstrobe.com](http://www.precisionstrobe.com)  
US Pat 5777248